

Sensors

UNIT-IV

Smart sensors and devices

09 Hrs


RFID and IONT materials: Synthesis, properties and applications in logistic information, intelligent packaging systems (Graphene oxide, carbon nanotubes (CNTs) and polyaniline).

Sensors: Introduction, types of sensors (Piezoelectric and electrochemical), nanomaterials for sensing applications (Strain sensors, gas sensor, biomolecules and volatile organic compounds).





Sensor: It is device that measures change in a physical (heat, light, sound, pressure etc) and/or chemical (pH, smell, taste, concentration, humidity etc) parameters of interest in an environment and transforms it into an electronic signal.

Transducer: A transducer is a device that transforms a signal from one energy form to another energy form.




Piezoelectric (PE) Sensors

- “Piezo” is word derived from Greek, it means for “press” or “squeeze”.
- A device, which converts physical parameters like acceleration, strain, pressure, vibration, temperature, or force into an electrical charge which can then be measured.
- Fabrication by using the perovskite ceramic material (lead zirconate titanate (PZT)) and also other lead-free ceramic piezoelectric sensors using bismuth sodium titanate (BST), barium titanate (BaTiO_3), boride and silicide ceramics (TiB_2 , TaSi_2 , WSi_2)



Mechanism




Characteristics of PE sensors:

- High strength
- High stability
- High voltage output
- highly flexible
- Wide frequency range
- Impact resistance
- High mechanical strength
- Elastic compliance etc


Strain Sensor: Upon applying the external force on an object, the strain (permanent/temporary) is induced in the object due to its structural (internal) deformation, this results in change in internal resistance of the object, which can be measured by using the device called strain sensor. Various nanomaterials like graphene, CNT, PVDF, and their hybrids are used in these sensors.

- ❖ **Pulse measurement** – PE sensors are very sensitive to record pulse measurements and effective in monitoring the patients' health.
- ❖ **Stethoscopes** – Due to high sensitivity and robustness PE sensors, they are often used within stethoscopes.
- ❖ **Anesthesia Effectiveness** - PE sensors are capable of accurately measuring the muscles stimulations, and hence can be helpful in understanding the effectiveness of anesthesia.
- ❖ **Sleep Studies** - PE sensors can be attached to various parts of the patient body and can be used to measure the smallest movements of patients during the sleep also.


Respiration Monitoring




Pulse Monitoring



Drug Delivery




Healthcare and Biomedical Engineering




Soft Robotics



Soft Prosthetic Hand



Artificial Skin



Soft Robotic Grippers


Sport Performance Monitoring



Whole Body Monitoring



Joint Motion Detection




Smart Wearable Strain Sensor


Gaming and Virtual Reality



Soft Virtual Reality Glove



Wireless Smart Glove



Interactive Gaming

Electrochemical (EC) Sensors: a device that converts chemical composition data of the analyte into an analytically usable signal.


Components: (a) electrodes system, (b) transducer (c) amplifier and (d) recorder.

(a) electrode system consist

- Working electrode (Working electrode (WE) is very sensitive to any change in analyte solution, provides the surface for the analyte to undergo reaction. Example- Carbon, glassy carbon electrode (GCE))
- Counter/auxiliary electrode (The CE helps in completing the circuit by allowing the reaction, which is opposite to WE reaction, to happen. If an oxidation reaction happens at WE, reduction reaction will take place at CE, and vice versa. Example- Gold, platinum and carbon electrodes)
- Reference electrode (The RE is independent of the analyte and other ions concentration. Example- Standard Hydrogen Electrode (SHE), calomel electrode, silver-silver chloride)


Working principle: The basic principle of EC sensor is that it measures the current produced by chemical reactions in the electrochemical system.

- Potentiostat - controls the voltage between two electrodes (WE and RE).
- when the potential is applied between WE and RE.
- RE potential is constant while measuring the potential of WE.
- By measuring the current of redox reaction, the analyte can be identified.



If an oxidation reaction happens at WE, reduction reaction will take place at CE, and vice versa.. By measuring the current of redox reaction, the analyte can be identified.





- The EC sensor used to for various analytes such as hydrogen peroxide, glucose, urea, alcohol etc,
- which are adsorbed on receptors (nanomaterials, Graphene, CNTs metal oxides).
- They undergo redox reaction upon applying voltage
- The resultant current (electrons released) is measured by transducer, which is characteristic property of a biomolecule under study.
- Then the current is quantified by using amplifier and recorder as shown below.




Electrochemical (EC) Sensors: electrodes

Conventional carbon based probes:


- graphite
- carbon paste
- pyrolytic graphite
- glassy carbon





Polished graphite- glassy carbon



Electrochemical (EC) Sensors: Screen printed electrodes



- A. ink; B. squeegee;
C. printing mask;
D. printing mesh;
E. frame; F. printed ink




Advantages:

- Dimension
- Disposable
- Low-Cost




Electrochemical (EC) Sensors: mechanism


The biological element translates the info of the biochemical domain (e.g. concentration) into a chemical or physical signal with a certain selectivity




Mechanism of binding analyte




adsorption




covalent
binding



entrapment





cross-linking




Glucose sensor

In EC sensor, glucose and oxygen react in the presence of nanomaterials or glucose oxidase (GOx) functionalized WE, and thus oxygen is consumed and hydrogen peroxide is produced. Further, the glucose concentration can be detected indirectly by electron transfer of oxygen at CE


WE:




CE:




Electrochemical sensor :Ascorbic acid sensor



*EFSA health claim 13.1, **14 infants & young children





Electrochemical sensor :Ascorbic acid sensor




Screen Printed Carbon Electrode
Example- CE(silver), WE (CNT), RE(CNT)


Ascorbic acid sensor using poly aniline



Volatile organic matter detection




Volatile organic matter detection




Furniture	Pesticides
Cosmetics	Adhesives
Laminates	Paint solvents
Detergents	Tobacco smoke
Fabric softeners	Traffic emissions
Air fresheners	Stored Fuels
Plastics	Lubricants
Carpets	Auto Parts
Dyes	Molds


Volatile organic matter detection: Applications




Electrochemical Gas sensors








Electrochemical Gas sensors: Types



Electrochemical Gas sensors: Materials



Chemical reactions involved in gas sensing




Electrochemical Gas sensors: Applications

- Process control industries
- Environmental monitoring
- Boiler control
- Fire detection
- Alcohol breath tests
- Detection of harmful gases in mines
- Home safety
- Grading of agro-products like coffee and spices


THANK YOU

Glucose sensor


(a) First-generation glucose sensors



(c) Single nanomaterial sensors



(b) Second-generation sensors



(d) Nanocomposite sensors

